

**PIN IN & OUT CONNECTIONS
FOR 903 BOARD**

P 101		Common		P102		Common	
Coin A	27	b	Red/White	Speaker	Yellow/Red	22	
Coin B	a	Black	U	Speaker GND		23	
Play	21	Green	25	Video Red	Red	28	
Deal/Draw	e	Brown/Black	b	Video Green	Green	27	
Discard 1	T	Orange/Black	19	Video Blue	Blue	26	
Discard 2	S	White/Black	19	Video GND	Black	e	
Discard 3	R	Red/Black	19	Video Vertical	White	d	
Discard 4	P	Black/White	19	Video Horizontal	Yellow	f	
Discard 5	N	Yellow/Black	19	Meter #1	Brown	B	
Cancel	d	Black	b	Meter #2	Blue	C	
Double	f	Green/Black	b	Meter A.C.	Green	D & E	
Take	22	Brown	25	A.C. 15V Ret.	White/Black	12	
Big (Odd)	23	Orange	25	A.C. 15V IN	Black/White	13	
Small (Even)	24	White	25				
Key Switch	20	White	25				
Test	V	Grey	U				
Audit	W	Black	U				
Clear	X	Yellow	U				
	Y	Blue	U				
<hr/>							
Play	10	Blue/White	6				
Deal/Draw	11	White/Orange	6				
Double/Take	14	Yellow	6				
Big/Small	15	Grey	6				
Discard 1 & 2	12	Green/White	6				
Discard 3,4, &5	13	Brown/White	6				
<hr/>							
P 101							
-5V	1 & A	Red					
-12V	2 & B & 7 & E	White					
GND	3 & C & F	Black					