

Jungle

(USA - VA2.XX)

SW 1		1	2	3	4	5	6	7	8
Main Game Chance	90%	Off	Off	Off					
	85%	Off	Off	On					
	80%	Off	On	Off					
	75%	Off	On	On					
	70%	On	Off	Off					
	65%	On	Off	On					
	60%	On	On	Off					
	55%	On	On	On					
Min. Bet To Start The Game	1				Off	Off			
	5				Off	On			
	10				On	Off			
	20				On	On			
Max. Bet	50						Off	Off	
	100						Off	On	
	200						On	Off	
	300						On	On	
Win Points To Score	Yes								Off
	No								On

SW 2		1	2	3	4	5	6	7	8
Coin In Setting	1	Off	Off	Off					
	2	Off	Off	On					
	5	Off	On	Off					
	10	Off	On	On					
	20	On	Off	Off					
	25	On	Off	On					
	50	On	On	Off					
	100	On	On	On					
Key In Setting	1				Off	Off	Off		
	4				Off	Off	On		
	5				Off	On	Off		
	15				Off	On	On		
	25				On	Off	Off		
	75				On	Off	On		
	100				On	On	Off		
	500				On	On	On		
Pay out mode (ticket)	Fixed	10 credit 1 ticket						Off	Off
		20 credit 1 ticket						Off	On
		50 credit 1 ticket						On	Off
	Adjustable	(SW 2 No. 4 - 6)						On	On

Jungle (USA - VA2.XX)

SW 3		1	2	3	4	5	6	7	8
Game Limit	10000	Off	Off						
	50000	Off	On						
	100000	On	Off						
	200000	On	On						
Credit Limit	5000			Off					
	10000			On					
Display Rate Table	Yes				Off				
	No				On				
Reel Auto Stop	Yes				Off				
	No				On				
Game Count Mode	Normal					Off			
	Count					On			
Reel Speed	slow					Off			
	Fast					On			
Min. Bet For Fever	5							Off	
	15							On	

SW 4		1	2	3	4	5	6	7	8	
Double - Up Chance	85%	Off								
	75%	On								
Game Name	Yes		Off							
	No		On							
Pay out Mode (Ticket)	Manual			Off						
	Auto			On						
Double - Up	Yes				Off					
	No				On					
Strip Girl Available	Jungle					Off				
	Girl					On				
Key Down Mode	1 / Time					Off	Off	Off		
	4 / Time					Off	Off	On		
	5 / Time					Off	On	Off		
	15 / Time					Off	On	On		
	25 / Time					On	Off	Off		
	75 / Time					On	Off	On		
	100 / Time					On	On	Off		
	500 / Time					On	On	On		

Jungle

(USA - VA2.XX)

36 PIN	COMPONENT SIDE A	SOLDER SIDE B	36 PIN
1	Video Red	Video Green	1
2	Video Blue	Video SYNC	2
3	Speaker	Speaker GND	3
4-6			4-6
7	Ticket Out Button - On Panel		7
8	Ticket Notch - From Dispenser		8
9	Start / All Stop		9
10	Small / Stop 2		10
11	Play / Stop 4		11
12	Take / Stop 3 / Hold		12
13	Double Up / Stop 1		13
14-15			14-15
16	Big / Outer Reels Stop		16
17			17
18	Coin	Key In	18
19			19
20	Book	Test	20
21		Key Down	21
22			22
23	Meter : Coin		23
24	Meter : Key In		24
25-27			25-27
28	Meter : Key Down / Pay Out		28
29	Start / All Stop Lamp		29
30	Small / Stop 2 Lamp		30
31	Play / Stop 4 Lamp		31
32	Take / Stop 3 / Hold Lamp		32
33	Double / Stop 1 Lamp		33
34	Big / Outer Reels Stop Lamp		34
35			35
36	GND	GND	36

10 PIN	COMPONENT SIDE A	SOLDER SIDE B	10 PIN
1-2	GND	GND	1-2
3-4	+5V	+5V	3-4
5	+12V	+12V	5
6			6
7	Ticket Dispenser Enable / HPSSR		7
8			8
9-10	GND	GND	9-10