

MAGICAL  
005


MAGICAL ODDS

Dipsw-1	1	2	3	4	5	6	7	8
COIN A								
1 COIN 5 CREDIT	<del>OFF</del>	<del>OFF</del>	<del>OFF</del>	<del>OFF</del>	<del>OFF</del>	<del>OFF</del>	<del>OFF</del>	<del>OFF</del>
2	ON	OFF	OFF					
1	OFF	ON	OFF					
10	ON	ON	OFF					
20	OFF	OFF	ON					
25	ON	OFF	ON					
40	OFF	ON	ON					
50	ON	ON	ON					
KEY IN								
1 COIN 50 CREDIT				<del>OFF</del>	<del>OFF</del>	<del>OFF</del>		
40				ON	OFF	OFF		
25				OFF	ON	OFF		
20				ON	ON	OFF		
10				OFF	OFF	ON		
5				ON	OFF	ON		
60				OFF	ON	ON		
100				ON	ON	ON		
COIN C								
1 COIN 25 CREDIT							<del>OFF</del>	<del>OFF</del>
10							ON	OFF
5							OFF	ON
50							ON	ON

Dipsw-2	1	2	3	4	5	6	7	8
Payout percentage of the Main Game								
56% -4	ON	ON	ON					
60% +3	OFF	ON	ON					
64% +2	<del>ON</del>	<del>OFF</del>	<del>ON</del>					
68% +1	OFF	OFF	ON					
72% =0	ON	ON	OFF					
76% -1	OFF	ON	OFF					
80% -2	ON	OFF	OFF					
84% -3	OFF	OFF	OFF					
Nude lady in the screen				<del>ON</del>				
No nude lady in the screen				OFF				
Tied up to OFF					<del>OFF</del>	<del>OFF</del>		
Tied up to OFF							<del>OFF</del>	



Dipsw-4	1	2	3	4	5	6	7	8
Credit In limit								
IN No limit	OFF	OFF						
3,000	ON	OFF						
2,000	OFF	ON						
1,000	ON	ON						
Hopper Switch								
N.C.			ON					
N.O.			OFF					
Tied up to OFF				OFF				
COIN D								
1 COIN 1 CREDIT					OFF	OFF	OFF	OFF
1 2					ON	OFF	OFF	OFF
1 3					OFF	ON	OFF	OFF
1 4					ON	ON	OFF	OFF
1 5					OFF	OFF	ON	OFF
1 10					ON	OFF	ON	OFF
2 5					OFF	ON	ON	OFF
2 3					ON	ON	ON	OFF
2 1					OFF	OFF	OFF	ON
3 1					ON	OFF	OFF	ON
3 2					OFF	ON	OFF	ON
4 3					ON	ON	OFF	ON
4 1					OFF	OFF	ON	ON
5 2					ON	OFF	ON	ON
5 1					OFF	ON	ON	ON
10 1					ON	ON	ON	ON



VIDEO RED  
GREEN  
BLUE  
SYNC  
SPEAKER  
GND

1 |  
1 |  
2 |  
1 | 2  
3 |  
3 |  
4 |  
1 | 4  
5 |  
1 | 5  
6 |  
1 | 6  
7 |  
1 | 7  
8 |  
1 | 8  
9 |  
1 | 9  
10 |  
1 | 10  
11 |  
1 | 11  
12 |  
1 | 12  
13 |  
1 | 13  
14 |  
1 | 14  
15 |  
1 | 15  
15 |  
1 | 15  
17 |  
1 | 17  
18 |  
1 | 18  
19 |  
1 | 19  
20 |  
1 | 20  
21 |  
1 | 21  
22 |  
1 | 22  
23 |  
1 | 23  
24 |  
1 | 24  
25 |  
1 | 25  
25 |  
1 | 25  
27 |  
1 | 27  
27 |  
1 | 27  
28 |  
1 | 28  
29 |  
1 | 29  
30 |  
1 | 30  
30 |  
1 | 30  
31 |  
1 | 31  
31 |  
1 | 31  
32 |  
1 | 32  
32 |  
1 | 32  
33 |  
1 | 33  
33 |  
1 | 33  
34 |  
1 | 34  
34 |  
1 | 34  
35 |  
1 | 35  
35 |  
1 | 35

- 1 PLAYER START SW
- 2 PLAYER "
- 1 PLAYER ODDS/SMALL
- 2 PLAYER "
- 1 PLAYER BET SW
- 2 PLAYER "
- 1 PLAYER TAKE SCORE
- 2 PLAYER "
- 1 PLAYER DOUBLE UP
- 2 PLAYER "
- 1 PLAYER BIG X
- 2 PLAYER BIG X
- 1 PLAYER SMALL X
- 2 PLAYER SMALL X
- 1 PLAYER FLIPPLOP/BIG
- 2 PLAYER "

- COIN SW A
- KEY IN SW
- COIN SW B
- COIN SW C
- BOOKS SW
- TEST SW
- PAY OUT SW
- KEY SW
- HOPPER COIN FULL SW
- HOPPER COIN SW
- COUNTER A
- LOCK OUT COIL A
- COUNTER KEY IN
- COUNTER B
- LOCK OUT COIL B
- COUNTER C
- LOCK OUT COIL C(CHIPS)
- HOPPER COUNTER
- COUNTER(LACK OF CHIPS)
- KEY SW COUNTER

- 1 PLAYER START LAMP
- 2 PLAYER "
- 1 PLAYER CANCEL LAMP
- 2 PLAYER "
- 1 PLAYER BET LAMP
- 2 PLAYER BET LAMP
- 1 PLAYER TAKE SCORE LAMP
- 2 PLAYER "
- 1 PLAYER DOUBLE UP LAMP
- 2 PLAYER "

